

11241EVS ROTARY HAMMER

Pos.	Part Number	Description {Qty.}	F/C	Pos.	Part Number	Description {Qty.}	F/C
1	1 615 102 155	Motor Housing	71	131	1 611 110 C71	Label	9
2	1 614 220 163	Field	22	134	2 910 110 116	Screw	89
4	1 617 200 094	Switch	15	135	1 614 431 031	Cable	10
		w/pos. 818		137	2 916 699 130	Lock Washer	65
5	1 614 461 035	Cord	11	138	1 611 015 053	Gasket	79
6	1 610 703 056	Strain Relief	11	141	1 610 290 066	Seal	77
7	1 601 302 019	Clamp	89	142	1 610 290 069	Seal	77
9	1 611 110 C58	Label	9	143	1 614 601 021	Spring Ring	89
13	1 610 900 026	Ball Bearing	60	144	1 610 251 006	Washer	86
14	1 610 905 028	Ball Bearing	61	145	1 610 119 012	Retaining Ring	89
15	1 616 610 090	Fan	23	146	1 610 210 174	O-Ring	78
21	1 610 508 038	Dust Shield	92	154	2 916 660 023	Retaining Ring	89
22	1 610 591 027	Sleeve	86	160	1 610 210 161	Ring	9
23	1 610 520 001	Stop Sleeve	86	162	1 610 210 163	O-Ring	78
25	1 612 300 036	Locking Cog {2}	86	165	1 610 210 079	O-Ring	78
26	1 610 290 076	Disc	86	167	1 610 283 033	Seal	77
27	1 610 591 028	Air Deflector	24	171	1 613 435 016	Screw {6}	89
28	1 614 621 000	Spring	86	172	1 613 435 013	Screw {4}	89
30	1 610 502 011	Disc	86	174	1 613 435 012	Screw {6}	89
31	1 610 290 049	Bushing	82	175	2 912 401 018	Screw {2}	89
34	1 610 516 013	Flange	9	176	1 613 435 012	Screw {2}	
37	1 615 500 315	Bracket	9	177	1 603 435 051	Screw {2}	89
38	1 615 190 101	Cover	9	192	1 614 611 019	Spring	27
42	1 614 336 046	Bush Holder	25	195	1 613 435 020	Screw {2}	89
		w/pos. 811, 817		198	1 618 900 001	Lever	64
43	1 615 500 322	Cover	70	200	1 610 284 000	Bellows	9
44	1 614 617 003	Spring	27	202	1 611 010 006	Hook {2}	9
47	1 610 300 064	Sleeve	82	203	1 610 322 009	Washer {2}	65
48	1 616 334 012	Sleeve	82	803	1 614 011 109	Armature Assembly	AW
51	1 616 333 041	Gear	33			w/pos. 13, 14, 15, 95, 111, 112, 141, 145	
53	1 610 290 068	Washer	65	808	1 611 104 999	Nameplate	9
57	1 618 710 074	Striker	44	811	1 617 014 135	Brush Set	26
72	1 616 317 064	Eccentric Gear	34	817	1 614 652 004	Brush Spring {2}	27
74	1 611 921 001	Plate	9	818	2 910 011 082	Screw {2}	89
75	1 615 132 087	Handle	74	821	1 617 000 842	Bushing Assembly	82
79	1 613 435 015	Screw {2}	89			w/pos. 121, 142, 167	
80	1 617 233 033	Speed Control	17	835	1 617 000 433	Guide Tube Assembly	43
81	1 615 132 088	Handle Cover	74			w/pos. 25	
84	1 612 025 054	Auxiliary Handle	9	840	1 617 000 847	Gear Housing Assembly	72
85	1 618 040 074	Clamp Holder	80			w/pos. 95, 104, 141, 145	
86	1 613 490 001	T-Bolt	80	849	1 617 000 839	Fork Assembly	62
87	1 611 316 019	Clamping Band	80	856	1 617 000 843	Piston Assembly	47
94	1 610 102 056	Washer {2}	65			w/pos. 165	
95	1 610 210 173	O-Ring	78	860	1 617 000 844	Clutch Assembly	67
97	1 610 031 005	Washer	65	873	1 617 000 861	Gear Housing Cover	70
99	1 610 102 059	Washer	65			w/pos. 138	
* 102	1 610 102 057	Shim	65	884	1 612 025 055	Auxiliary Handle	9
* 102	1 610 102 058	Shim	65			w/pos. 84, 85, 86, 87	
104	1 610 210 160	O-Ring	78	891	1 617 000 853	Shock Absorber	9
111	1 610 290 064	Bushing	82			w/pos. 200	
112	1 613 300 008	Nut	89	895	1 615 430 019	Oil	1
113	1 613 435 009	Screw {2}	89	897	1 617 000 430	Service Pack	78
116	1 610 311 017	Bushing	82			w/pos. 21, 25, 138, 143, 162, 165, 811	
117	1 610 913 004	Needle Bearing {2}	56	898	1 615 437 511	Oil w/pos. 138	1
121	1 610 328 019	Bushing	82				
124	1 610 115 001	Sleeve	82				
126	2 910 211 019	Screw	89				